



THE CUT IS REQUIRED TO BE FREE OF FOREIGN DEBRIS.

ANY EXCESS OVERFLOW FROM THE CUTTING PROCESS IS TO BE REMOVED.

REMOVE PACKING MATERIAL IF POSSIBLE BEFORE THE SAWCUT AND RE-USE. RE-PACK THE EXPANSION JOINT WITH CITY APPROVED PACKING MATERIAL.

 **LITEACCESS**
TECHNOLOGIES INC
LA336EXP-JNT1PR.DWG

RUNNING LINE IN EXISTING EXPANSION JOINT

MICRODUCT 3/36 CABLE SYSTEM

MIN BEND RAD:
THIN DIRECTION: 140mm
WIDE DIRECTION: 300mm

MAX INSTALLATION PULL FORCE: 800N (80kg)

OUTER SHEATH REMOVAL: SHEATH CUTTERS WITH CARE

INNER SHEATH REMOVAL: USE RIPCORD PROVIDED

TOP OF UTILITY CANNOT BE CLOSER THAN 20mm (3/4") TO THE SURFACE

TOP OF UTILITY SHOULD BE AT 1-1/4" DEPTH TO LEAVE ROOM FOR RE-PACKING THE EXPANSION JOINT

FOLLOW EXPANSION JOINT, COLD JOINT, PANEL JOINT, OR GUTTER EDGE WHEREVER POSSIBLE. CONSULT WITH MUNICIPAL OR ROW AUTHORITY PRIOR TO BEGINNING WORK. COMPLY WITH LOCAL REGULATIONS REGARDING SAW CUT RESTORATION FOR THIS TYPE OF SURFACE COVER.

SAWCUT DETAIL - CONCRETE SURFACE

- EXPANSION JOINT - SCALE: N.T.S. - UPDATED 20070804

DISCLAIMER

THE LOCATIONS OF UTILITIES OR STRUCTURES SHOWN ON THIS DRAWING ARE APPROXIMATE ONLY. AXISS TECHNOLOGIES, LLC & BSE HEREBY DISCLAIMS ANY RESPONSIBILITY TO THIRD PARTIES FOR THE ACCURACY OF THIS INFORMATION. PERSONS PERFORMING SURFACE INLAY WORK MUST CONTACT THE APPROPRIATE CALL-BEFORE-YOU-DIG SYSTEM TO ASCERTAIN THE LOCATION OF UNDERGROUND UTILITIES PRIOR TO PERFORMING ANY EXCAVATION, DRILLING, OR SAWCUTTING